

Step 1 **Masonry Walls or Cement Walls**

Drill a hole at the marked position with an electric drill and drilling bit.

MADE IN TAIWAN

UP

8mm

55mm(2.17)

10mm (3/8)

Note: For a brick-piled masonry wall or cement wall, holes of 10mm diameter and 55mm depth shall be made.

Step 2 **Stud Walls**

8mm

55mm(2.17)

4.5mm (3/16)

Note: For a stud wall, holes of 4.5mm diameter and 55mm depth shall be made.

Step 3

Step 4

5mm

0.5mm

Step 5

Step 6

N

Step 7

T

U

Step 8

C

B

2-3mm

Step 9

Q

Step 10

LOCK

Step 11

K

±5°

Wall Mount Tilt Angle

K

L

5mm

Step 12 **Cable Management**

P

S

Projector Tilt Angle

Knob

B(Yellow) C(Black) A(Grey)

Knob A Grey

Step 1

Step 2

±10°

SWIVEL

Knob B Yellow

Step 3

Step 4

±10°

Knob C Black

Step 5

±10°

Step 6

±20MM

Step 7

LOCK

C

Step 7

L

5mm